

Hoop Pine Plywood 2400x1200x9.5mm/12.5mm FIXING Set-Out

Pre Installation Care

1. Check to see if material has arrived in satisfactory condition.
2. Keep flat on 4 bearers.
3. Keep in dry environment.
4. Two people to lift panel off pack. Do not drag panel off the pack.
5. Pre drill hole and countersink.
6. Top Hats to be at 600mm Centres.
7. Type 8 screw @ 40mm.
8. Design speed (permissible stress) 41 metres / second non cyclonic.
9. Seal over screw with silicon dot or water based polyurethane finish.

